

## 4-channel encoder pulse counter, 8-channel DO, Modbus TCP module WJ96

### Product features:

- Encoders decode and convert to standard Modbus RTU protocol
- Can be used as an encoder counter or speed measurement
- Supports simultaneous counting of 4 encoders and can recognize forward and reverse rotation
- Built in 8 DOs can be used as encoder upper and lower limit alarm outputs
- Power off automatically saves counter data
- Built in DO, each channel can independently output PWM signals
- Supports Modbus TCP communication protocol
- Built in web page function, which can query the level status through the web page
- Wide power supply range: 8~32VDC
- High reliability, easy programming, and easy application
- Standard DIN35 rail installation, convenient for centralized wiring
- Users can set module IP addresses and other parameters on the webpage
- Web login can set a password for greater security
- Low cost, small size, modular design
- Dimensions: 120 x 70 x 43mm




diagram 1 WJ96 module appearance diagram

### Typical applications:

- Encoder pulse signal measurement
- Displacement or angle measurement
- Motor speed measurement and control
- Replace the meter counter to control multiple devices
- The encoder signal is transmitted remotely to the industrial computer
- Intelligent factory and industrial Internet of Things
- Replace PLC to directly transmit data to the control center
- IoT switch signal acquisition

### Product Overview:

The WJ96 product realizes signal acquisition between sensors and hosts, which is used to decode encoder signals and control devices. The WJ96 series products can be applied in IoT and industrial Ethernet control systems, automated machine tools, industrial robots, three coordinate positioning systems, displacement measurement, stroke measurement, angle measurement, speed measurement, and more.





Figure 2 Internal Block Diagram of WJ96 Module

The WJ96 series products include power conditioning, encoder signal acquisition, transistor output, and RJ-45

network interface communication. The communication method adopts MODBUS TCP protocol. TCP is a transport layer based protocol that is widely used and a reliable connection oriented protocol. Users can directly set module IP addresses, subnet masks, etc. on the webpage. Can be used for monitoring and controlling the operation of sensor devices.

The WJ96 series products are intelligent monitoring and control systems based on microcontrollers, where user set module IP addresses, subnet masks, and other configuration information are stored in non-volatile memory EEPROM.

The WJ96 series products are designed and manufactured according to industrial standards, with strong anti-interference ability and high reliability. The working temperature range is -45 °C to +85 °C.

### Function Introduction:

The WJ96 remote I/O module can be used to measure four encoder signals and has eight switch outputs. It can be used as a 4-channel encoder counter or 4-channel speed measurement, and can also output 8-channel PWM signals.

#### 1、Signal input and output

4-channel encoder signal input, can be connected to dry and wet contacts, please refer to the wiring diagram for details; 8-channel switch signal output with open collector output.

#### 2、Communication Protocol

Communication interface: RJ-45 network interface. The two indicator lights at the network port position, the Link light (green light) stays on after the network cable is plugged in, and the Data light (yellow light) will flash intermittently.

Communication protocol: MODBUS TCP protocol is adopted to achieve industrial Ethernet data exchange. You can also access the control module directly through the webpage.

Network cache: 2K bytes (for both sending and receiving)

Communication response time: less than 10mS.

#### 3、anti-interference

There is a transient suppression diode inside the module, which can effectively suppress various surge pulses and protect the module.

### Product model:

#### WJ96 - RJ45

Communication interface \_\_\_\_\_

**RJ45:** Output as RJ-45 network interface

### WJ96 General Parameters:

(Typical @+25 °C, Vs is 24VDC)

Input type: Encoder AB signal input, 4-channel (A0/B0~A3/B3).

Low level: Input < 1V

High level: Input 3.5~30V

Frequency range 0-50KHz

Counting range -2147483647 ~ +2147483647, automatically saved upon power failure

Input resistance: 30K Ω

Output type: open collector output, voltage 0~30V, maximum load current 30mA, 8 channels (DO0~DO7).

PWM frequency 1~65535Hz, duty cycle 0%~100%

Communication: MODBUS TCP communication protocol

Web page: Supports web access module and web page setting module parameters.

Interface: RJ-45 network interface with built-in isolation transformer.

Working power supply: +8~32VDC wide power supply range, with internal anti reverse and overvoltage protection circuits

Power consumption: less than 1W

Working temperature: -45~+80 °C

Working humidity: 10~90% (no condensation)

Storage temperature: -45~+80 °C

Storage humidity: 10~95% (no condensation)

Isolation voltage resistance: non isolated

Dimensions: 120mm x 70mm x 43mm

**Factory default parameters for WJ96:**

### Configuring Network

Module Name:	WJ96-RJ45
MAC Address:	1C:6B:8B:CB:BE:92
IP Address:	192.168.0.7
Subnet Mask:	255.255.255.0
Gateway:	192.168.0.1
Work Mode:	Websocket ▼
Local Port Number:	23
Remote Port Number:	23
Remote Server IP:	192.168.0.201
Automatically Uploading:	Yes ▼
Upload Time Interval:	1000 ms
Version:	1.0
Password:	<div style="display: flex; align-items: center;"> <input style="width: 100px; height: 20px; margin-right: 5px;" type="text"/> <span style="font-size: 0.9em;">one hundred and twenty-three thousand four hundred and</span> </div> <div style="display: flex; align-items: center; margin-top: 5px;"> <span style="font-size: 0.9em;">fifty-six</span> </div>
<div style="display: flex; justify-content: center; gap: 20px;"> <span style="border: 1px solid #ccc; padding: 5px 15px; background-color: #f0f0f0;">Save and Reboot</span> <span style="border: 1px solid #ccc; padding: 5px 15px; background-color: #f0f0f0;">Default Settings</span> </div>	

**Figure 3: WJ96 Factory Default Parameters**

#### 1. How to restore factory settings?

- 1、 When the module is powered on, turn the Initiat switch to the Initiat position and then back to the NORMAL position.
- 2、 Wait for 30 seconds, the module will automatically return to factory settings. The parameters are shown in Figure 3. The webpage login password is automatically restored to 123456.

#### Pin definition and wiring:

Pin	name	Description	Pin	name	Description
one	DO7	Channel 7 switch signal output terminal	twelve	DO2	Channel 1 switch signal output terminal
two	DO6	Channel 6 switch signal output terminal	thirteen	GND	Negative terminal of power supply, signal common ground

<b>three</b>	DO5	Channel 5 switch signal output terminal	<b>fourteen</b>	A0	Encoder 0 signal A input terminal
<b>four</b>	DO4	Channel 4 switch signal output terminal	<b>fifteen</b>	B0	Encoder 0 signal B input terminal
<b>five</b>	DO3	Channel 3 switch signal output terminal	<b>sixteen</b>	A1	Encoder 1 signal A input terminal
<b>six</b>	PW+	Positive end of power supply	<b>seventeen</b>	B1	Encoder 1 signal B input terminal
<b>seven</b>	PW+	Positive end of power supply	<b>eighteen</b>	A2	Encoder 2 signal A input terminal
<b>eight</b>	GND	Negative terminal of power supply, signal common ground	<b>nineteen</b>	B2	Encoder 2 signal B input terminal
<b>nine</b>	RJ-45	network interface	<b>twenty</b>	A3	Encoder 3 signal A input terminal
<b>ten</b>	DO0	Channel 0 switch signal output terminal	<b>twenty-one</b>	B3	Encoder 3 signal B input terminal
<b>eleven</b>	DO1	Channel 1 switch signal output terminal	<b>twenty-two</b>	GND	Negative terminal of power supply, signal common ground

Note: The pins **with the** same name are internally connected








Figure 5 Wiring diagram of WJ96 module

**Encoder alarm output port**

Encoder 0 upper limit alarm output port	DO0
Encoder 1 upper limit alarm output port	DO1
Encoder 2 upper limit alarm output port	DO2
Encoder 3 upper limit alarm output port	DO3



Encoder 0 lower limit alarm output port	DO4
Encoder 1 lower limit alarm output port	DO5
Encoder 2 lower limit alarm output port	DO6
Encoder 3 lower limit alarm output port	DO7

**Encoder signal input wiring diagram**

<p style="text-align: center;"><b>NPN encoder</b></p>  <p style="text-align: center;">Need to open the internal pull-up resistor, set the 40082 register to 1, or send the character command \$01Q1X</p>	<p style="text-align: center;"><b>NPN encoder with pull-up resistor</b></p>  <p style="text-align: center;">Need to turn off the internal pull-up resistor, set the 40082 register to 0, or send the character command \$01Q0X</p>
<p style="text-align: center;"><b>PNP encoder</b></p>  <p style="text-align: center;">Need to turn off the internal pull-up resistor, set the 40082 register to 0, or send the character command \$01Q0X</p>	<p style="text-align: center;"><b>Push-pull encoder</b></p>  <p style="text-align: center;">Need to turn off the internal pull-up resistor, set the 40082 register to 0, or send the character command \$01Q0X</p>

**Note:** The factory default is to turn off the pull-up function

**Wiring diagram for switch signal output**

<p style="text-align: center;"><b>Drive Relay</b></p>  <p>External power supply can be selected from 5~30VDC It can also be a power source that supplies power to the module The working current of the transistor is less than 30mA</p>	<p style="text-align: center;"><b>Level output</b></p>  <p>Output high level equal to power supply voltage Need to open the internal pull-up resistor, set the 40083 register to 1, or send the character command \$01QX1.</p>
---	--

Need to turn off the internal pull-up resistor, set the 40083 register to 0, or send the character command \$01QX0


**Note: The factory default is to turn off the pull-up function**

### Modbus TCP protocol

Please connect using Modbus dedicated port 502. The port number set on the webpage is invalid.

#### (1) Modbus TCP data frames:

Transmission over TCP/IP Ethernet, supporting Ethernet II and 802.3 frame formats. As shown in Figure 3, the Modbus TCP data frame consists of three parts: packet header, function code, and data.



**Figure 6:** Request/Response of MODBUS on TCP/IP

#### (2) MBAP message header description:

The MBAP header (MBAP, Modbus Application Protocol, Modbus Application Protocol) is divided into 4 fields, totaling 7 bytes, as shown in Table 1.

Table 1: MBAP Message Header

Domain	Length (B)	Description
Transmission identification	2 bytes	Indicate the transmission of a MODBUS query/response
Protocol Logo	2 bytes	0=MODBUS protocol
Length	2 bytes	Subsequent byte count
Unit identifier	1 byte	Identification code of remote slave station connected on serial link or other bus

#### (3) Modbus function code:

Modbus function codes are divided into three types, namely:

- (1) Public Function Code: Defined function codes that ensure their uniqueness and are recognized by Modbus.org;
- (2) There are two sets of user-defined function codes, namely 65-72 and 100-110, which do not require approval but do not guarantee the uniqueness of code usage. If it becomes public code, it needs to be approved by RFC;
- (3) The reserved functional code, which is used by certain companies on certain traditional devices, cannot be used for public purposes.

Among the commonly used public function codes, WJ96 supports some function codes, as shown below:

Function code	name	explain
01	Read Coil Status	Read coil status 1 represents high level, 0 represents low level.
03	Read Holding Register	Read and hold register 1 represents high level, 0 represents low level.
05	Write Single Coil	Write a single coil 1 indicates that the transistor is conducting, and

			0 indicates that the transistor is disconnected.
06	Write Single Register	Write a single register	1 indicates that the transistor is conducting, and 0 indicates that the transistor is disconnected.
fifteen	Write Multiple Coils	Write multiple coils	
sixteen	Write Multiple Registers	Write multiple registers	

#### (4) Description of supported function codes

##### 01 (0x01) Reading coil

In a remote device, use this function code to read the continuous status of the coil from 1 to 2000. The request PDU specifies the starting address, which is the designated first coil address and coil number. Address the coil from scratch. Therefore, addressing coils 1-16 are 0-15.

Divide the coils in the response message into individual coils based on each bit in the data field. The indication status is 1=ON and 0=OFF. The first data serves as the LSB (least significant bit) of the byte, and the subsequent coil data is arranged in ascending order to form an 8-bit byte. If the returned output quantity is not a multiple of eight, the remaining bits in the last data byte will be filled with zeros (up to the high-order end of the byte). The byte count field indicates the complete number of bytes in the data

Example of function code 01, read 8-channel DI data, register addresses 00033~00040:

request			response		
Field Name		hexadecimal	Field Name		hexadecimal
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			
	length	00		length	00
		06			04
Unit identifier	01	Unit identifier	01		
Function code		01	Function code		01
Starting address Hi		00	Byte count		01
Starting address Lo		twenty	Output status DI7-DI0		00
Output quantity Hi		00			
Output quantity Lo		08			

##### 03 (0x03) Read hold register

In a remote device, use this function code to read the contents of consecutive blocks in the hold register. The request PDU specifies the starting register address and the number of registers. Address registers from scratch. Therefore, addressing registers 1-16 are 0-15. In the response message, each register has two bytes, with the first byte being the data high bit and the second byte being the data low bit.

Example of function code 03, read 8-channel DI data, register address 40033:

request		response	
Field Name	hexadecimal	Field Name	hexadecimal

		al			
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			00
	length	00		length	00
06		05			
Unit identifier	01	Unit identifier	01		
Function code		03	Function code		03
Starting address Hi		00	Byte count		02
Starting address Lo		twenty	Register value Hi (0x00)		00
Register number Hi		00	Register value Lo (DI7-DI0)		00
Register number Lo		01			

### 05 (0x05) Write a single coil

On a remote device, use this function code to write a single output as ON or OFF. The request PDU specifies the mandatory coil address. Address the coil from scratch. Therefore, addressing coil address 1 is 0. The constant of the coil range indicates the requested ON/OFF state. Hexadecimal value 0xFF00 requests the coil to be ON. Hexadecimal value 0x0000 requests the coil to be OFF. All other values are illegal and have no effect on the coil. The correct response is the same as a request.

For example, for function code 05, set channel DO0 to ON, which is 1, and register address 00001:

request			response		
Field Name		hexadecimal	Field Name		hexadecimal
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			00
	length	00		length	00
06		06			
Unit identifier	01	Unit identifier	01		
Function code		05	Function code		05
Output Address Hi		00	Output Address Hi		00
Output address Lo		00	Output address Lo		00
Output value Hi		FF	Output value Hi		FF
Output value Lo		00	Output value Lo		00



### 06 (0x06) Write a single register

In a remote device, use this function code to write a single hold register. The request PDU specifies the address written to the register. Address registers from scratch. Therefore, address register address 1 is 0.

The correct response is the same as a request.

For example, for function code 06, set all channels DO0~DO7 to 1, hexadecimal to 0xFF, and register address 40001:

request			response		
Field Name		hexadecimal	Field Name		hexadecimal
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			00
	length	00		length	00
06		06			
Unit identifier	01	Unit identifier	01		
Function code		06	Function code		06
Register Address Hi		00	Register Address Hi		00
Register Address Lo		00	Register Address Lo		00
Register value Hi		00	Register value Hi		00
Register value Lo		FF	Register value Lo		FF

### 15 (0x0F) Write multiple coils

On a remote device, use this function code to write multiple outputs as ON or OFF. The request PDU specifies the mandatory coil address. Address the coil from scratch. Therefore, addressing coil address 1 is 0. The constant of the coil range indicates the requested ON/OFF state. The data is converted from hexadecimal to binary and arranged in bits, with a bit value of 1 requesting the coil to be ON and a bit value of 0 requesting the coil to be OFF.

For example, for function code 15, set channel DO0 and DO1 to ON, which is 00000011, and register address 00001:

request			response		
Field Name		hexadecimal	Field Name		hexadecimal
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			00
	length	00		length	00
06		06			
Unit identifier	01	Unit identifier	01		

Function code	0F	Function code	0F
Start address Hi	00	Start address Hi	00
Starting address Lo	00	Starting address Lo	00
Number of coils Hi	00	Number of coils Hi	00
Number of coils Lo	02	Number of coils Lo	02
Byte count	01		
Output value	02		

### 16 (0x10) Write multiple registers

In a remote device, use this function code to write multiple hold registers. The request PDU specifies the address written to the register. Address registers from scratch. Therefore, address register address 1 is 0. Example of function code 16, set the PWM values for channels DO0 and DO1 to 5 and 6, register address 40001:

request		response	
Field Name	hexadecimal	Field Name	hexadecimal
MBAP message header	Transmission identification	MBAP message header	Transmission identification
	Protocol Logo		Protocol Logo
	length		length
Unit identifier	Unit identifier		
Function code	ten	Function code	ten
Start register address Hi	00	Start register address Hi	00
Start register address Lo	00	Start register address Lo	00
Number of registers Hi	00	Number of registers Hi	00
Number of registers Lo	02	Number of registers Lo	02
Byte count	04		
Register value Hi	00		
Register value Lo	05		
Register value Hi	00		
Register value Lo	06		

### (5) Register Address Description for WJ96

Supports registers with function codes 01, 05, and 15

Address (PLC)	Address (PC, DCS)	Data content	attribute	Data Explanation
00001	0	Output switch quantity	Read/Write	Output status of channels 0~7 0 indicates that the transistor is disconnected, 1 indicates that the transistor is conducting
00002	one	Output switch quantity	Read/Write	
00003	two	Output switch	Read/	

		quantity		Write	
00004	three	Output quantity	switch	Read/Write	
00005	four	Output quantity	switch	Read/Write	
00006	five	Output quantity	switch	Read/Write	
00007	six	Output quantity	switch	Read/Write	
00008	seven	Output quantity	switch	Read/Write	
00009	eight	Output quantity	switch	Read/Write	Reset output status of channels 0-7 (default value is 0)
00010	nine	Output quantity	switch	Read/Write	0 indicates that the transistor is disconnected after resetting, 1 indicates that the transistor conducts after resetting
00011	ten	Output quantity	switch	Read/Write	
00012	eleven	Output quantity	switch	Read/Write	
00013	twelve	Output quantity	switch	Read/Write	
00014	thirteen	Output quantity	switch	Read/Write	
00015	fourteen	Output quantity	switch	Read/Write	
00016	fifteen	Output quantity	switch	Read/Write	
00017	sixteen	Channel 0 output inversion		Read/Write	Channels 0~7, (default value is 0) 0 indicates normal PWM output, 1 represents the output after PWM inversion
00018	seventeen	Channel 1 output is reversed		Read/Write	
00019	eighteen	Channel 2 output inversion		Read/Write	
00020	nineteen	Channel 3 output inversion		Read/Write	
00021	twenty	Channel 4 output inversion		Read/Write	
00022	twenty-one	Channel 5 output inversion		Read/Write	
00023	twenty-two	Channel 6 output inversion		Read/Write	
00024	twenty-three	Channel 7 output inversion		Read/Write	
00033	thirty-two	A0 input	switch	read-on	The level state of the encoder input point

		quantity	ly	0 represents a low-level input, 1 represents a high-level input
00034	thirty-three	B0 input switch quantity	read-on ly	
00035	thirty-four	A1 input switch quantity	read-on ly	
00036	thirty-five	B1 input switch quantity	read-on ly	
00037	thirty-six	A2 input switch quantity	read-on ly	
00038	thirty-seven	B2 input switch quantity	read-on ly	
00039	thirty-eight	A3 input switch quantity	read-on ly	
00040	thirty-nine	B3 input switch quantity	read-on ly	

Supports registers with function codes 03, 06, and 16

Address 4X (PLC)	Address (PC, DCS)	Data content	attribute	Data Explanation
forty thousand and one	0	PWM0	Read/Write	Output channels 0-7, PWM output value, Integer, range 0~10000
forty thousand and two	one	PWM1	Read/Write	
forty thousand and three	two	PWM2	Read/Write	
forty thousand and four	three	PWM3	Read/Write	
forty thousand and five	four	PWM4	Read/Write	
forty thousand and six	five	PWM5	Read/Write	
forty thousand and seven	six	PWM6	Read/Write	
forty thousand and eight	seven	PWM7	Read/Write	
forty thousand and nine	eight	Channel 0~3 pulse frequency	Read/Write	Output PWM pulse frequency, (default value is 0) Integer, range 0~65535 Hz Set to 0, indicating switch output Set to 1~65535, indicating PWM output
forty thousand and ten	nine	Channel 4-7 pulse frequency	Read/Write	
40017~40018	16~17	Encoder 0 count	Read/Write	Encoder 0-3 counter The data is a signed long integer in hexadecimal format, with negative numbers using two complement,
40019~40020	18~19	Encoder 1 Count	Read/Write	

40021~40022	20~21	Encoder 2 Count	Read/ Write	Positive numbers (0x0000000~0x7FFFFFFF),
40023~40024	22~23	Encoder 3 Count	Read/ Write	Negative numbers (0xFFFFFFFF~0x8000001),
				Reset the counter and directly write 0 to the corresponding register, Other values can also be written as needed. If there is an alarm, modifying the count value will automatically clear the alarm.
forty thousand and twenty-seven	twenty-six	Count reset register	Read/ Write	Unsigned integer, default to 0 Modify this register to reset the count value of the encoder. After modification, the register will automatically return to 0. Write 10: Set the encoder 0 count value to 0, Write 11: Set the count value of encoder 1 to 0, Write 12: Set the count value of encoder 2 to 0, Write 13: Set the count value of encoder 3 to 0, Write 14: Set all encoder count values to 0, Writing other values is invalid, do not reset the encoder. If there is an alarm, resetting the count value will automatically clear the alarm.
forty thousand and twenty-nine	twenty-eight	Number of pulses for encoder 0	Read/ Write	Unsigned integer (default value at factory is 1000), set according to the number of pulses per revolution of the encoder, and registers 40101~40104 are the corresponding channel speeds after setting.
forty thousand and thirty	twenty-nine	Pulse count of encoder 1	Read/ Write	
forty thousand and thirty-one	thirty	Pulse count of encoder 2	Read/ Write	
forty thousand and thirty-two	thirty-one	Pulse count of encoder 3	Read/ Write	
forty thousand and thirty-three	thirty-two	Encoder 0 working mode	Read/ Write	Integer, range 0x0000-0x0005 0x0000, default value, normal mode 0x0001, upper limit alarm mode 0x0002, lower limit alarm mode 0x0003, both upper and lower limit alarm modes 0x0004, standby mode, temporarily not needed 0x0005, standby mode, temporarily not needed
forty thousand and thirty-four	thirty-three	Encoder 1 working mode	Read/ Write	
forty thousand and thirty-five	thirty-four	Encoder 2 working mode	Read/ Write	
forty thousand and thirty-six	thirty-five	Encoder 3 working mode	Read/ Write	

Address 4X (PLC)	Address (PC, DCS)	Data content	attribute	Data Explanation
				needed
				<b>Note: In alarm mode, DO is used as a switch alarm output and cannot be used as a PWM output.</b>
40041~40042	40~41	Encoder 0 upper limit value	Read/Write	Encoder 0-3 upper limit alarm value and lower limit alarm value, The default value is 0. The data is a signed long integer in hexadecimal format, with negative numbers using two complement, Positive numbers (0x0000000~0x7FFFFFFF), Negative numbers (0xFFFFFFFF~0x8000001),
40043~40044	42~43	Encoder 1 upper limit value	Read/Write	
40045~40046	44~45	Encoder 2 upper limit value	Read/Write	
40047~40048	46~47	Encoder 3 upper limit value	Read/Write	
40049~40050	48~49	Encoder 0 lower limit value	Read/Write	
40051~40052	50~51	Encoder 1 lower limit value	Read/Write	
40053~40054	52~53	Encoder 2 lower limit value	Read/Write	
40055~40056	54~55	Encoder 3 lower limit value	Read/Write	
forty thousand and fifty-seven	fifty-six	Encoder 0 upper limit time	Read/Write	
forty thousand and fifty-eight	fifty-seven	Encoder 1 upper limit time	Read/Write	
forty thousand and fifty-nine	fifty-eight	Encoder 2 upper limit time	Read/Write	
forty thousand and sixty	fifty-nine	Encoder 3 upper limit time	Read/Write	
forty thousand and sixty-one	sixty	Encoder 0 lower limit time	Read/Write	
forty thousand and sixty-two	sixty-one	Encoder 1 lower limit time	Read/Write	
forty thousand and sixty-three	sixty-two	Encoder 2 lower limit time	Read/Write	
forty thousand and sixty-four	sixty-three	Encoder 3 lower limit time	Read/Write	
forty thousand and sixty-five	sixty-four	PWM0 reset output value	Read/Write	PWM reset output values for channels 0 to 7, (The default value is 5000) Integer, range 0~10000
forty thousand and sixty-six	sixty-five	PWM1 reset output value	Read/Write	
forty thousand and sixty-seven	sixty-six	PWM2 reset output value	Read/Write	
forty thousand	sixty-seven	PWM3 reset output	Read/	

and sixty-eight		value	Write	
forty thousand and sixty-nine	sixty-eight	PWM4 reset output value	Read/Write	
forty thousand and seventy	sixty-nine	PWM5 reset output value	Read/Write	
forty thousand and seventy-one	seventy	PWM6 reset output value	Read/Write	
forty thousand and seventy-two	seventy-one	PWM7 reset output value	Read/Write	
forty thousand and seventy-three	seventy-two	Channel 0~3 frequency reset value	Read/Write	Pulse frequency reset output value, (default value is 0) Integer, range 0~65535 Hz Set to 0, indicating switch output Set to 1~65535, indicating PWM output
forty thousand and seventy-four	seventy-three	Channel 4-7 frequency reset value	Read/Write	
forty thousand and eighty-one	eighty	Encoder count value automatically saved	Read/Write	0: Do not automatically save, power off and reset to zero; 1: Power off automatically saves the encoder count value. (Default value is 1)
forty thousand and eighty-two	eighty-one	DI's pull-up switch	Read/Write	0: DI turns off the pull-up voltage; (default value is 0) 1: Connect the pull-up voltage to DI.
forty thousand and eighty-three	eighty-two	DO's pull-up switch	Read/Write	0: DO turns off the pull-up voltage; (default value is 0) 1: Connect the pull-up voltage to DO.
forty thousand and eighty-nine	eighty-eight	Parameter reset to factory settings	Read/Write	If set to FF00, all register parameters of the module will be restored to factory settings, and the module will automatically restart after completion
forty thousand one hundred and one	one hundred	Encoder 0's rotational speed	read-only	Signed integer, positive or negative indicates positive or negative reversal. The speed is calculated based on the number of pulses set in registers 40029~40032.
forty thousand one hundred and two	one hundred and one	Speed of encoder 1	read-only	
forty thousand one hundred and three	one hundred and two	Speed of encoder 2	read-only	
forty thousand	one hundred and	The speed of encoder	read-on	

one hundred and four	three	3	ly	
40129~40130	128~129	The frequency of encoder 0	read-only	32-bit floating-point number, collected frequency. The storage order is CDAB.
40131~40132	130~131	Frequency of Encoder 1	read-only	
40133~40134	132~133	Frequency of Encoder 2	read-only	
40135~40136	134~135	The frequency of encoder 3	read-only	
forty thousand two hundred and eleven	two hundred and ten	Module Name	read-only	High bit: 0x00 Low bit: 0x96

### Character Protocol Socket Communication

In working modes such as Websocket, TCP Server, TCP Client, UDP Mode, the following character protocols can be used for communication.

If the automatic data upload is set to "Yes" in the configuration settings,  
In Websocket, TCP Server, TCP Client, UDP Mode

自动上传数据:  是  否  
 上传时间间隔:  ms

In working mode, data will be automatically uploaded after successful communication connection.

#### 1. Read switch status command

Description: Read back all output channel switch status, switch reset status, and input channel switch status from the module.

Command format: # 01

Response format: >AAAAAAA,BBBBBBB,CCCCCCC commands are valid.

? The 01 (cr) command is invalid or an illegal operation.

Parameter description: >delimiter. Hexadecimal is 3EH

AAAAAAA represents the read output switch status, consisting of 8 numbers arranged in the order of DO7~DO0,

Value 0: Output transistor disconnected; Value 1: Output transistor connected

BBBBBBB represents the read reset output switch status, consisting of 8 numbers arranged in the order of DO7~DO0,

Value 0: Output transistor disconnected; Value 1: Output transistor connected

CCCCCCC represents the read input switch status, consisting of 8 numbers arranged in the order of DI7~DI0,

Value 0: Output transistor disconnected; Value 1: Output transistor connected

Application example: User command (character format) # 01

Module response (character format) >00011000001100000111

(Hexadecimal format): 213032303130300D

Explanation: The module output switch status is 00011000, arranged in the order of DO7~DO0

Channel 0: transistor disconnected Channel 1: transistor disconnected Channel 2: transistor disconnected  
Channel 3: transistor connected

Channel 4: transistor connected Channel 5: transistor disconnected Channel 6: transistor disconnected  
Channel 7: transistor disconnected



After resetting the module, the output switch status is 00001010, arranged in the order of DO7~DO0

Channel 0: transistor disconnected Channel 1: transistor connected Channel 2: transistor disconnected  
Channel 3: transistor connected

Channel 4: transistor disconnection Channel 5: transistor disconnection Channel 6: transistor disconnection  
Channel 7: transistor disconnection

The input switch status of the module is 00000 111, and the arrangement order is DI7~DI0

Channel 0: High Level Channel 1: High Level Channel 2: High Level Channel 3: Low Level

Channel 4: Low Level Channel 5: Low Level Channel 6: Low Level Channel 7: Low Level

## 2. Set transistor output command

Description: Set the status of all output channel transistors. The factory setting for all channels is 00000000.

Command format: # **011ABCD**

Parameter description: # delimiter. Hexadecimal is 24H

011 represents the command to set the transistor output

**AB** channel selection, can choose all output channels or a single output channel.

Set output: Setting AB to 00 means setting all output channels. If setting a single channel, character A must be set to 1, and character B can be set to 0-7, representing 8 transistor DO output channels.

Set reset output: Setting AB to FF means setting the reset output values for all channels. If setting the reset output for a single channel, character A must be set to E, and character B can be set to 0-7, representing 8 transistor DO output channels.

**CD** output value.

- 1, If it is set for all channels (AB=00 or AB=FF)

Then there are two hexadecimal numbers, as shown in the figure on the right

C represents channels 7 to 4

D represents channels 3 to 0

Bit value is 0:

Set the output transistor to

C				D			
DO7	DO6	DO5	DO4	DO3	DO2	DO1	DO0

disconnect

Bit value is 1:

Set the output transistor to turn on

- 2, If it is set for a single channel (AB=1X or AB=EX, where X represents the channel to be set), it can only be set to 00 or 01,

00: Set the X-channel output transistor to disconnect

01: Set the X-channel output transistor to turn on

Response format: ! The **01 (cr)** command is valid.

? The **01 (cr)** command is invalid or an illegal operation.

Application Example 1: User Command (Character Format) # **011000F**

Module response (character format) ! **01(cr)**

Explanation: Set the output of all channels (AB=00) to 0FH, and convert it to binary to 0000 1111,

So the switch state output by the module is:

Channel 0: transistor connected Channel 1: transistor connected Channel 2: transistor connected Channel 3:  
transistor connected

Channel 4: transistor disconnection Channel 5: transistor disconnection Channel 6: transistor disconnection  
Channel 7: transistor disconnection

Application Example 2: User Command (Character Format) # **0111201**

Module response (character format) > **(cr)**

Explanation: Set the transistor of channel 2 to be connected.

Application Example 3: User Command (Character Format) # **011FFFF**

Module response (character format)! **00(cr)**

Explanation: Set the reset output of all channels (AB=FF) to FFH, which is converted to binary as 1111 1111,

After the module is reset, all channel transistors are turned on.

### 3. Read encoder counter data command

Explanation: Reading the data from the encoder counter can read all encoders or a single encoder Indicates forward rotation, '-' indicates reverse rotation.

Command format: # **012** Read data from channel 0 to channel 3 encoder counter

Response format: + **AAAAAAAAAA, +AAAAAAAAAA, +AAAAAAAAAA, +AAAAAAAAAA (cr)**

Command format: # **012N** Read channel N counter data

Response format: + **AAAAAAAAAA(cr)**

Application Example 1: User Command (Character Format) # **012**

Module response (character format) + **0012345678, +0012345678, +0012345678, +0012345678 (cr)**

Explanation: The count values of all encoders are positive rotation+12345678.

Application Example 2: User Command (Character Format) # **0120**

Module response (character format) - **0012345678(cr)**

Explanation: The count value of encoder 0 is inverted-12345678.

### 4. Read input frequency command

Explanation: To read the input frequency, it can read all encoders or a single encoder Indicates forward rotation, '-' indicates reverse rotation.

Command format: # **013** Read encoder 0~Encoder 3 Input frequency

Response format: + **AAAAAA.AA, +AAAAAA.AA, +AAAAAA.AA, +AAAAAA.AA (cr)**

Command format: # **013N** Read Encoder N Input Frequency

Response format: + **AAAAAA.AA (cr)**

Application Example 1: User Command (Character Format) # **013**

Module response (character format) + **001000.00, +001000.00, +001000.00, +001000.00 (cr)**

Explanation: The input frequency value of all encoders is forward rotation+1kHz.

Application Example 2: User Command (Character Format) # **0130**

Module response (character format) - **001000.00(cr)**

Explanation: The input frequency value of encoder 0 is reversed to -1kHz.

### 5. Read and output PWM commands

Explanation: Reading the output PWM can read all channels, single channels, and reset PWM values.

Command format: # **014** Read PWM values for channels 0 to 7

Response format: ! **AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA(cr)**

Command format: # **014S** read channel 0~channel 7 reset PWM value

Response format: ! **AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA, AAA.AA(cr)**

Command format: # **014N** Read PWM value of channel N

Response format: ! **AAA.AA (cr)**

Command format: # **014SN** Read channel N's reset PWM value

Response format: ! **AAA.AA (cr)**

Application Example 1: User Command (Character Format) # **014**

Module response (character format)! **050.00,050.00,050.00,050.00,050.00,050.00,050.00,050.00(cr)**

Explanation: The PWM value for all channels is 50%.

Application Example 2: User Command (Character Format) # **0140**

Module response (character format)! **050.00(cr)**

Explanation: The PWM value for channel 0 is 50%.

### 6. Set PWM command

Explanation: Setting the output PWM value or resetting the PWM value can only be set for a single channel. The factory setting for all channels is 050.00.

Command format: # **015NAAA AA** sets the PWM value for channel N

Response format:! **01 (cr)** indicates successful setting

Command format: # **015SNAAA AA** sets the reset PWM value for channel N

Response format:! **01 (cr)** indicates successful setting

Application Example 1: User Command (Character Format) # **0150050.00**

Module response (character format)! **01(cr)**

Explanation: Set the PWM value for channel 0 to 50%.

Application Example 2: User Command (Character Format) # **015S0050.00**

Module response (character format)! **01(cr)**

Explanation: Set the reset PWM value for channel 0 to 50%.

### 7. Read the frequency command of PWM

Explanation: Read the output PWM frequency and also read the reset PWM frequency.

Command format: # **016** Read PWM frequency

Response format:! **AAAAA,BBBBB (cr)** AAAAA represents the frequency of channels 0-3, BBBBB represents the frequency of channels 4-7

Command format: # **016S** read reset PWM value

Response format:! **AAAAA,BBBBB (cr)** AAAAA represents the reset frequency of channels 0-3, BBBBB represents the reset frequency of channels 4-7

Application Example 1: User Command (Character Format) # **016**

Module response (character format)! **01000,02000(cr)**

Explanation: The PWM frequency for channels 0-3 is 1KHz, and the PWM frequency for channels 4-7 is 2KHz.

Application Example 2: User Command (Character Format) # **016S**

Module response (character format)! **00100,00200 (cr)**

Explanation: The PWM reset frequency for channels 0-3 is 100Hz, and the PWM reset frequency for channels 4-7 is 200Hz.

### 8. Set PWM frequency command

Explanation: To set the output PWM frequency or reset PWM frequency, only a single channel can be set. Range 00000~65535, set to 00000 to turn off PWM output and output as switch level output. The factory setting for all channels is 00000.

Command format: # **017NAAAA** N=0 indicates setting the PWM frequency for channels 0-3, N=1 indicates setting the PWM frequency for channels 4-7.

Response format:! **01 (cr)** indicates successful setting

Command format: # **017SNAAAAA** N=0 indicates setting the PWM reset frequency for channels 0-3,  
N=1 indicates setting the PWM reset frequency for channels 4-7.

Response format:! **01 (cr)** indicates successful setting

Application Example 1: User Command (Character Format) # **017000100**

Module response (character format)! **01(cr)**

Explanation: Set the PWM frequency of channels 0-3 to 100Hz.

Application Example 2: User Command (Character Format) # **017S100500**

Module response (character format)! **01(cr)**

Explanation: Set the reset PWM frequency for channels 4-7 to 500Hz.

### 9. Read input speed command

Explanation: Reading the input speed can read all encoders or a single encoder. Indicates forward rotation, '-' indicates reverse rotation.

Command format: # **018** Read encoder 0~Encoder 3 input speed.

Response format: + **AAAAA,+AAAAA,+AAAAA,+AAAAA (cr)**

Command format: # **018N** Read Encoder N Input Speed

Response format: + **AAAAA (cr)**

Application Example 1: User Command (Character Format) # **018**

Module response (character format) + **01000,+01000,+01000,+01000 (cr)**

Explanation: The input speed values of all encoders are forward rotation+1000 rotation.

Application Example 2: User Command (Character Format) # **0180**

Module response (character format) - **01000(cr)**

Explanation: The input speed value of encoder 0 is reversed to 1000 revolutions per minute.

### 10. Modify the numerical command of the encoder counter

Explanation: You can modify the value of the encoder counter or reset it to zero to start counting again. After modifying the count value, the alarm will be automatically cleared.

Command format: **\$011N+AAAAAAAAA** Modify the count value of encoder N. N is the encoder code, and setting N to 'A' means setting the counters of all encoders simultaneously.

Response format: **! 01 (cr)** indicates successful setting

Application example 1: User command (character format) **\$0113+000000000 (cr)**

Module response (character format) **! 01(cr)**

Explanation: Set the count value of encoder 3 to 0, and if there is an alarm, it will be automatically cleared.

Application example 2: User command (character format) **\$011A+000000000 (cr)**

Module response (character format) **! 01(cr)**

Explanation: Set the count value of all encoders to 0.

Application example 3: User command (character format) **\$011A+0000003000 (cr)**

Module response (character format) **! 01(cr)**

Explanation: Set the count value of all encoders to +3000, and if there is an alarm, it will be automatically cleared.

### 11. Set PWM output reverse command

Explanation: Set whether the PWM output needs to be inverted between high and low levels before outputting. The factory setting is 00000000.

Command format: **\$013BBBBB** Set whether PWM output takes the reverse command.

Response format: **! 01 (cr)** indicates successful setting

Parameter description: **BBBBBB** represents the switch state, with 8 numbers arranged in the order of DO7~DO0

Value 0: The PWM output of this channel is normal; Value 1: The PWM of this channel takes the inverse output

Application example: User command (character format) **\$013000000**

Module response (character format) **! 01(cr)**

Explanation: Set all channel PWM to output normally.

### 12. Read whether the PWM output takes the reverse command

Explanation: Check if the PWM output is set to reverse.

Command format: **\$014** Read PWM output to determine if the command is reversed.

Response format: **BBBBBBB (cr)** indicates whether the PWM output is set to reverse

Parameter description: **BBBBBB** represents the switch state, with 8 numbers arranged in the order of DO7~DO0

Value 0: The PWM output of this channel is normal; Value 1: The PWM of this channel takes the inverse output

Application example: User command (character format) **\$014**

Module response (character format) **! 1111110(cr)**

Explanation: The 0-channel PWM outputs normally, while the 1-7 channel PWM outputs in reverse.

### 13. Set the number of pulses per revolution for the encoder

Description: Set the number of pulses per revolution for the encoder. Set according to the parameters of the connected encoder, with a factory default value of 1000. The encoder speed can only be read after setting the correct number of pulses.

Command format: **\$015NAAAA** sets the number of pulses per revolution for the encoder. **AAAAA** represents the number of pulses, such as 1000800 or 600 and so on.

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$015100300**

Module response (character format) **! 01(cr)**

Explanation: Set the number of pulses per revolution for encoder 1 to 300.

### 14. Read the number of pulses per revolution of the encoder

Explanation: Read the number of pulses per revolution for all encoders.

Command format: **\$016** reads the number of pulses per revolution for all encoders, arranged in order of 0-3.

Response format: **! AAAAA, AAAAA, AAAAA, AAAAA (cr)** represents the number of pulses per revolution from encoder 0 to encoder 3.

Application example: User command (character format) **\$016**

Module response (character format) **! 01000, 01000, 01000, 01000 (cr)**

Explanation: The number of pulses per revolution for all encoders is 1000.

### 15. Set the working mode of the encoder

Description: Set the working mode of the encoder.

Command format: **\$017NAA** sets the working mode of the encoder.

**AA** represents the working mode. Range 00~05, **in alarm mode, DO is used as a switch alarm output and cannot be used as a PWM output.**

00, default value, normal mode

01, Upper limit alarm mode

02, Lower limit alarm mode

03, both upper and lower limit alarm modes

04, standby mode, temporarily not needed

05, standby mode, temporarily not needed

**(cr)** End symbol, upper computer enter key, hexadecimal is 0DH.

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$017101**

Module response (character format) **! 01(cr)**

Explanation: Set encoder 1 to the upper limit alarm mode.

### 16. Read the working mode of the encoder

Description: Read the working mode of all encoders.

Command format: **\$018** reads the working mode of all encoders, arranged in order of 0-3.

Response format: **! AA, AA, AA, AA (cr)** represent the working modes of encoders 0 to 3.

Application example: User command (character format) **\$018**

Module response (character format) **! 03, 03, 03, 03 (cr)**

Explanation: All encoders are in alarm mode for both upper and lower limits.

### 17. Set the upper and lower alarm values for the encoder

Explanation: Set the upper and lower alarm values of the encoder, and activate the alarm according to different working modes.

Command format: **\$01SN+AAAAAAAAA,+BBBBBBBB** Set the upper and lower alarm values for the encoder.

**S** sets the encoder alarm value command.

**N** encoder code, with values ranging from 0 to 3.

**+AAAAAAAAA** represents the upper limit alarm value.

**+BBBBBBBB** represents the lower limit alarm value.

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$01S0+0123456790, -00000 12345**

Module response (character format) **! 01(cr)**

Explanation: Set encoder 0 to have an upper limit alarm value of 1234567890 and a lower limit alarm value of -12345.

### 18. Set the alarm time for the encoder

Description: Set the alarm time command for the encoder. The alarm time, with a default value of 0, indicates that both the alarm signal and the counter need to be cleared by instructions from the upper computer. If it is any other value, multiplying it by 0.01 seconds will result in the actual duration of the alarm. After reaching the alarm time, the alarm signal will automatically clear and the count value of the encoder will also automatically reset to zero.

Command format: **\$01TNAAAAA,BBBBB** Set the upper and lower alarm times for the encoder.

Set the encoder alarm time command for **T**.

**N** encoder code, with values ranging from 0 to 3.

**AAAAA** represents the upper limit alarm time. Range 0~65535.

**BBBBB** represents the lower limit alarm time. Range 0~65535.

Response format: **! AA (cr)** indicates successful setting

Application example: User command (character format) **\$01T10500002000**

Module response (character format) **! 01(cr)**

Explanation: Set encoder 1 to have an upper limit alarm time of 50 seconds and a lower limit alarm time of 20 seconds.

### 19. Read the upper limit alarm value, lower limit alarm value, and alarm time of the encoder

Description: Read the upper limit alarm value, lower limit alarm value, and alarm time of the specified encoder.

Command format: **\$01R** reads the alarm time of all encoders, arranged in an upper limit of 0-3 and a lower limit of 0-3.

Response format: **+AAAAAAAAA, +AAAAAAAAA, +AAAAAAAAA, +AAAAAAAAA, +BBBBBBBBBB, +BBBBBBBBBB, +BBBBBBBBBB, +BBBBBBBBBB, CCCCC, CCCCC, CCCCC, CCCCC, DDDDD, DDDDD, DDDDD(cr)**

**+AAAAAAAAA** represents the upper limit alarm value of encoder 0~encoder 3

**+BBBBBBBBBB** represents the lower limit alarm value of encoder 0~encoder 3

**CCCCC** represents the upper limit alarm time for encoders 0 to 3.

**DDDDD** represents the lower limit alarm time of encoders 0 to 3.

Application example: User command (character format) **\$01R**

Module response (character format) **+ 0000012345, +0000012345, +0000012345, +0000012345, -0000002000, -0000002000, -0000002000, 03000, 03000, 03000, 03000, 03000, 03000, 03000, 03000 (cr)**

Explanation: The upper limit alarm value of all encoders is +12345, and the lower limit alarm value is

-2000,

The upper and lower alarm times are both 30 seconds.

### 20. Set whether the encoder count value is automatically saved when the power is turned off

Explanation: Set the count value of the encoder to automatically save when powered off. The factory default value is 1 (automatically saved when powered off).

Command format: **\$01XW**

Parameter description: **X** sets whether the count value of the encoder is automatically saved when the power is turned off.

**W** 0: Do not automatically save, power off and reset to zero; 1: Power off automatically saves the encoder count value.

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$01X0**

Module response (character format) **! 01(cr)**

Explanation: Set the encoder to not save count values and automatically reset the count after power failure.

### 21. Set the pull-up switches for DI and DO

Description: Set the pull-up switch for DI and DO, with a factory default value of 00 (both DI and DO have the pull-up function turned off).

Command format: **\$01QXY**

Parameter description: **Q** sets the pull-up switch command for DI and DO.

**X** 0: DI turns off the pull-up voltage; 1: Connect the pull-up voltage to DI. **X**: Keep the original settings.

**Y** 0: DO turns off the pull-up voltage; 1: Connect the pull-up voltage to DO. **X**: Keep the original settings.

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$01Q11**

Module response (character format) **! 01(cr)**

Explanation: Set both DI and DO to apply pull-up voltage. When DI is an NPN input, it can be set to turn on the DI pull-up voltage.

When DO requires voltage output, it can be set to turn on the DO pull-up voltage.

### 22. Set up automatic reporting of data

Description: Set up automatic reporting of data. The module will automatically report the data you need according to the settings.

Command format: **\$01CX** sets the data to be automatically reported. The upload code for X is as follows:

0: Automatically upload DI switch status (factory default)

1: Automatically upload encoder count values

2: Automatically upload encoder frequency

3: Automatically upload encoder speed

4: Automatically upload encoder count values, DI switch status, and speed

5: Automatically upload encoder count values, DI switch status, frequency, and speed

Response format: **! 01 (cr)** indicates successful setting

Application example: User command (character format) **\$01C1**

Module response (character format) **! 01(cr)**

Description: Set up automatic upload of DI count values.

### 23. Reset all parameters set by the above character commands to factory settings.

Explanation: The parameters set by the above character commands in the module will be reset to factory settings, and the module will automatically restart after completion. The network parameters such as module IP will not change.

Command format: **\$01900** Set parameters to factory settings.

Response format: **! 01 (cr)** indicates successful setup, and the module will automatically restart.

Application example: User command (character format) **\$01900**

Module response (character format) **! 01(cr)**

Explanation: Parameters are reset to factory settings.

## Operations and settings on web pages

Enter the default module IP in the computer or mobile browser, which is 192.168.0.7 by default, to open the module webpage (provided that the computer IP or mobile IP is in the same network segment as the module, and logging in to the webpage requires logging in based on the current module's IP address). Enter the password, which is 123456 by default, and click "Login" to enter the data display interface. There is a Chinese English switch icon in the upper right corner, which can be clicked to switch between Chinese and English.

### 1, Real time collection of web pages:

Due to the use of WebSocket on this page to achieve real-time data collection from web pages,

It is recommended to use Google Chrome browser or IE10 browser for testing.

After successful connection, the webpage will automatically update data (note how the module works)

Must be set to 'Websocket', and automatic data upload must be set to

Yes, otherwise data cannot be obtained. Alternatively, the AI range can be set through the webpage

Waiting for parameters. If your mobile browser supports WebSocket, you can also use it

Mobile phone reads data.

### 2. Configure network parameters:

#### (a) Module Name

The default module name is WJ96-RJ45, and users can modify the module name as needed.

#### (b) MAC address

The MAC address can be changed according to user needs.

#### (c) IP address

The current IP address of the module is 192.168.0.7 by factory default, and the IP address can be modified.

#### (c) Subnet mask

Used to divide the subnet range size (usually 255.255.255.0), which users can modify.

#### (d) Default gateway

The necessary path to access the external network (usually filled in with the IP address of the router)

#### (d) Working methods

The default is Websocket, which supports up to 5 Websocket communications.

Can be set as TCP Server, TCP Client, UDP Mode, Modbus TCP, etc

Communication method. Under TCP Server mode, a maximum of 5 TCP servers are supported.

#### (c) Local port

The default local port is 23, which can be modified by the user.

#### (c) Remote port

Data Table

Channels	Data		
DO0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DO7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Encoder0 A	<input type="text" value="1"/>	<input type="text"/>	<input type="text"/>
Encoder0 B	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>
Encoder1 A	<input type="text" value="1"/>	<input type="text"/>	<input type="text"/>
Encoder1 B	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>
Encoder2 A	<input type="text" value="1"/>	<input type="text"/>	<input type="text"/>
Encoder2 B	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>
Encoder3 A	<input type="text" value="1"/>	<input type="text"/>	<input type="text"/>
Encoder3 B	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>

Configuring Network

Module Name:

MAC Address:

IP Address:

Subnet Mask:

Gateway:

Work Mode:

Local Port Number:

Remote Port Number:

Remote Server IP:

Automatically Uploading:

Upload Time Interval:  ms

Version:

Password:



The working mode is TCP Client, and UDP Mode is filled in according to the actual situation.

**(e) Remote server address**

It is the IP address of the remote server.

The working mode is TCP Client, and UDP Mode is filled in according to the actual situation.

**(e) Automatically upload data**

In Websocket, TCP Server, TCP Client, UDP Mode and other modes,

Do you need to automatically upload measurement data.

**(f) Upload time interval**

The time interval for automatic uploading of measurement data. The default is to upload data once every second.

**(b) Version number**

The version increases from 1.0 onwards.

**(g) , Password**

Setting parameters requires entering the correct password to take effect. The password is the web login password, which defaults to 123456 at the factory.

After completing the parameter filling, click the "Save and Restart" button, and the module will save the parameters and automatically restart.

### Common problems with WJ96

#### 1. Cross network segment issues

If the IP of the device and the communicating PC are not in the same network segment and are directly connected via Ethernet or under the same sub router, then the two cannot communicate at all.

give an example:

Device IP: 192.168.0.7

Subnet mask: 255.255.255.0

PC's IP: 192.168.1.100

Subnet mask: 255.255.255.0

Due to the device's IP being 192.168.0.7, it is unable to log in to the device's webpage or ping it on the PC.

If you want the two to communicate, you need to set the subnet mask of the device and PC, as well as the subnet mask on the router, to 255.255.0.0, so that you can log in to the module webpage.

#### 2. The device can ping, but the webpage cannot be opened

There may be several reasons for this:

- 1) The device has set a static IP address that conflicts with the IP addresses of existing devices in the network
- 2) The HTTP server port has been modified (default should be 80)
- 3) Other reasons

Solution: Reset the device to an unused IP address; Restore factory settings or enter the correct port when opening the browser.

#### 3. Every once in a while, there is a disconnection and reconnection

Every once in a while, there will be a phenomenon of disconnection and reconnection

Reason: There is an issue of IP address conflict between the serial server and other devices

#### 4. Communication is abnormal, network connection cannot be established, or search cannot be found

The firewall of the current computer needs to be turned off (in the Windows firewall settings)

Three local ports must not conflict, meaning they must be set to different values. Default values are 23, 26, and 29

Having illegal MAC addresses, such as full FF MAC addresses, may result in inability to connect to the target IP address or duplicate MAC addresses.

Illegal IP addresses, such as network segments that are not in the same network segment as the router, may not be able to access the external network.

### 5. Hardware problem search

Poor power supply from the power adapter or poor contact of the plug


If the power light and network port light are not on, it means there is no power supply or the hardware is broken

Network cable or network port hardware issues, check the status of the network port lights

There is a hardware issue with the network port. You can check the status of the network port, etc. The green light should be constantly on and the yellow light should be flashing, not constantly on or off. Otherwise, it is a hardware issue

Password error. If you forget the password, you can restore the factory configuration (with the module powered on, turn the Initiat switch to the Initiat position, and then turn it back to the NORMAL position. Wait for 30 seconds, and the module will automatically return to the factory settings. The parameters are shown in Figure 3. The webpage login password will be automatically restored to 123456.)

### Dimensions: (Unit: mm)



Can be installed on standard DIN35 rails

### guarantee:

Within two years from the date of sale, if the user complies with the storage, transportation, and usage requirements and the product quality is lower than the technical specifications, it can be returned to the factory for free repair. If damage is caused due to violation of operating regulations and requirements, device fees and maintenance fees shall be paid.

**Copyright:**

Copyright © 2021 Shenzhen Weijunrui Technology Co., Ltd.

Without permission, no part of this manual may be copied, distributed, translated, or transmitted. This manual is subject to modification and update without prior notice.

**Trademark:**

The other trademarks and copyrights mentioned in this manual belong to their respective owners.

Version number: V1.1

Date: September 2021